


TRANSMISSION / AXLE PARTS



TRANSMISSION TORQUE CONVERTER AND AXLE PARTS PROVIDES THE FINAL SOLUTION



BRAKE TRANSMISSION DISCS



KING PINS



HUB COVERS



BRAKE PEDALS



CONTRIBUTION TO IMPROVING SOIL VALUE

ESSC Brake Pedals / Valfs

www.essc.com.tr

No	Description	Model
2R0617	VALVE AS - BRAKE FOOT CONTROL	814 815 816 920 930 930R 950 966C 966R 980 980B
4V4154	VALVE AS - BRAKE	814B 815B 816B 824C 825C 826C 916 926 926A 936 936F 950B 950B/950E 950F 950F II 960F 966D 966F 966F II 970F 980C G916 G926 G936
119-6744	VALVE GP - BRAKE CONTROL	814F 815F 816F 924F 938F 950F 950F II 960F 966F 966F II 970F IT24F IT28F IT38F R1300 R1300G R1300G II
2R0696	TREADLE ASSEM	920 930 950
4D2287	VALVE AS	621 621B 621E 623 623B 623E 627 627B 631C 631D 631E 633C 633D 637 637D 637E 641 641B 768B 769 814 814B 815 816 816B 824C 825C 826C 916 920.
7D8075	VALVE AS	120G 130G 140G 768B 768C 769 769C 769D 771C 771D 772 772B 773 773B 773D 775B 775D 776 776C 776D 777 777B 777D 785 785B 789 789B 793 793B 793C
9V2434	TREADLE AS	815B 826C 926 936F 950F 950F II 980C 980F RM-250C RR-250B
030-0810	PEDAL HEAD	RT50

Parts Numbers are used for reference purposes only